

## PARTS ILLUSTRATION AND LIST

COLT GOVERNMENT MODEL  
MK IV/SERIES 80 PARTS

## DESCRIPTION

- |                                 |   |
|---------------------------------|---|
| 1. Barrel                       | 28. Main Spring Housing (arched)  |
| 2. Barrel Bushing               | 29. Main Spring Housing Pin   |
| 3. Barrel Link                  | 30. Main Spring Housing Pin Retainer  |
| 4. Barrel Link Pin              | 31. Plunger Lever   |
| 5. Disconnecter                 | 32. Plunger Spring  |
| 6. Ejector                      | 33. Plunger Spring F/P  |
| 7. Ejector Pin                  | 34. Plunger Tube  |
| 8. Extractor                    | 35. Rear Sight  |
| 9. Firing Pin                   | 36. Receiver  |
| 10. Firing Pin Plunger          | 37. Recoil Spring (2 different springs<br>for OFFICER'S ACP or DELTA ELITE) |
| 11. Firing Pin Spring           | 38. Recoil Spring Guide   |
| 12. Firing Pin Stop             | 39. Recoil Spring Plug  |
| 13. Front Sight                 | 40. Safety Lock   |
| 14. Grip Safety                 | 41. Safety Lock Plunger   |
| 15. Hammer                      | 42. Sear  |
| 16. Hammer Pin                  | 43. Sear Pin  |
| 17. Hammer Strut                | 44. Sear Spring   |
| 18. Hammer Strut Pin            | 45. Slide   |
| 19. Magazine Assembly           | 46. Slide Stop  |
| 20. Magazine Catch              | 47. Slide Stop Plunger  |
| 21. Magazine Catch Lock         | 48. Stock Set   |
| 22. Magazine Catch Spring       | 49. Stock Screw (4)   |
| 23. Magazine Follower           | 50. Stock Screw Bushing (4)   |
| 24. Magazine Spring (not shown) | 51. Trigger Assembly  |
| 25. Main Spring                 | 52. Trigger Bar Lever   |
| 26. Main Spring Cap             |   |
| 27. Main Spring Cap Pin         |   |

